

Galvanic Spa®?

Last Modified on 01/06/2022 11:58 pm MST

It's important to ensure that you give your device a wipe with a damp cloth after every use.

An amber icon will notify you when batteries are low and need to be replaced. Two AA batteries last several months with typical use, so you won't need to change them very often.
